

Instruction manual

LED reindeer with sleigh

Table of contents

1. Safety instructions and warnings
2. Explanation of symbols
3. Intended use
4. Safety instructions
5. Device components
6. Commissioning
7. Cleaning/ storage
8. Technical data
9. Disposal/ recycling

1. Safety instructions and warnings

This lamp complies with the prescribed safety regulations for electrical devices.

Read the operating instructions carefully before using the LED light.

Improper use can cause damage to people and property. People who are not familiar with the instructions are not allowed to operate the LED light.

Keep the operating instructions and the packaging carefully.

Children and young people are not allowed to use the LED light.

WARNING! Please read the detailed safety instructions before use (from page 2).

Failure to comply can result in electric shock, fire and/ or injury. Please keep all safety and other information and pass them on to subsequent users.

ELECTRIC SECURITY

Always check whether the available mains voltage corresponds to that specified on the type plate.

2. Explanation of symbols

Pay attention to all signs and symbols that are specified in this manual and on your product. Make a note of these signs and symbols. If you interpret the signs and symbols correctly, you can work more safely and better with the product.



WARNING! / ATTENTION!



Read the operating instructions before commissioning!

3. Intended use

This product is used exclusively for decorative accent lighting in indoor and outdoor areas (IP44). It is not suitable for lighting a room.

It is only approved for connection to alternating voltage (220-240 V/ 50-60 Hz).

Use is permitted indoors and outdoors. However, the lamp must not be operated in or under water. It must be set up and used in such a way that moisture, heavy soiling and excessive heating are avoided.

The entire luminaire must not be changed or converted!

The luminaire must not be connected to the mains supply while it is in the packaging.

The lamps cannot be replaced.

The cable cannot be replaced. If the cable is damaged, the product must be disposed of.

Any use other than that described above will damage this product.

In addition, this is associated with dangers such as short circuit, fire, electric shock, etc.

The safety instructions and the technical data must be observed.

This lamp was specially designed for private use and not for continuous commercial use.

Check this product for any shipping damage. Take your time and read these operating instructions carefully before starting up.

4. Safety instructions

Please read all safety and other notices before use.



- WARNING! There is a risk of electric shock, fire and/ or injury if the safety instructions are not

observed!

- Please keep all safety and other information.

- Before connecting to the mains, ensure that the mains voltage and type of current match the information on the type plate on the mains cable/ power supply unit.



- WARNING! Never immerse the product, power cord or plug and/ or power supply unit in water or other liquids. Risk of electric shock!



- ATTENTION! This is a decorative item and not a toy for children! Risk of injury! Please keep children away and supervise them.

- This product can be used by children from 8 years of age and persons with limited physical, sensory or mental capabilities or their inexperience or ignorance if they are supervised or have been instructed in the safe use of the product and have understood the resulting dangers.

Children are not allowed to play with the product. Cleaning and user maintenance must not be carried out by children unless they are 8 years and older and supervised.

- Keep children under 3 years away from the lamp if they are not under constant supervision.

- Children from 3 years of age and younger than 8 years of age may only switch the product on and off if they are supervised or have been instructed in the safe use of the product and have understood the resulting dangers, provided that the product has been placed in its normal position of use or installed. Children from 3 years of age and younger than 8 years of age are not allowed to connect the product to the mains, regulate or clean it or carry out any maintenance.



- **ATTENTION! Do not look directly into the light source!**

- Pull out the mains plug:

- when not in use
- when reassembling/ transporting
- before cleaning

- Always pull the plug, never the cable.



- WARNING! Do not touch the product, power cord/ plug and/ or power supply unit with damp/ wet hands. Risk of electric shock!

- DANGER! Do not use the product in the vicinity of explosive/ highly flammable locations, gas or electric heaters, open fires, candles or other heat sources. Fire hazard!

- Never use a product with a defect or with defective cables and plugs. Do not use the defective product anymore and have it checked by MIGROSService.

- This product is designed for household use and not for continuous commercial use.

Before you assemble/ set up this product, the following points must be observed:

- The light unit is splash-proof (IP44) and can be used indoors and outdoors.

ATTENTION! Keep the power cord and AC adapter away from water and other liquids, or operate in locations where there is water and other liquids could accumulate. Product should not operate under water. Minimum distance of 3 m from swimming pools, ponds, etc.

- In the event of damage of any kind, especially on the cable, housing (Tightness!), which ensure safe operation of the product, the power supply line should be immediately switched off, put this product out of operation and secure against restarting!

- Make sure that the power plug and the power supply unit are not damaged. If this product is damaged, it must no longer be used.

- Lay the power cord and any extension cords that may be required so that no one can trip over them or pull them unintentionally.

- Make sure that the power cord is not damaged. Avoid damaging the power cord by kinking it and making contact with sharp edges.

- The power socket must be near the lamp.

- The power plug must be easily accessible at all times.

- **DANGER!** Do not insert the plug of the light into the socket while it is in the packaging. Fire hazard!

- The packaging and instructions must be kept as they contain important information.

- Do not hang any objects on this product.

- **DANGER!** Do not cover this product with other objects. Fire hazard!

- Never connect the product electrically to other lights.


- The power cord of the power supply unit cannot be replaced or repaired. If the cable is damaged, the product must be disposed of.

- The LEDs in the lamp are not exchangeable.

- We recommend connecting the product via a residual current circuit breaker. If in doubt, ask a specialist.

5. Device components (A)

1. Reindeer head
2. Cable ties
3. Reindeer body with legs
4. Reindeer foot
5. Nail
6. Nail
7. Nail
8. Sled
9. Earth nail
10. Cable (approx. 1.5 m) with power plug (220-240 V)



Check the LED light for any transport damage. Take your time and read these operating instructions carefully before starting up.

6. Commissioning Assembly/ installation

WARNING! Pull the power plug before installing the light. Risk of electric shock!

The lamp must not be installed or operated in or under water.

The cables must be loose and not taut, as this can lead to cable breaks.

Do not connect the LED light to the power supply in the packaging.

- Pull out the mains plug
- Place the reindeer body (3) with legs and sledge on the ground
- Press the peg (5) all the way into the ground until it fixes a foot. Fix the diagonally opposite foot with a second peg (6).

Note: Do not use reindeer without a peg, otherwise it will fall over in the wind

- Insert the peg (7) into the ground directly next to the light hose until the hose is held in place with the bracket.

With the second peg (9) fix the diagonally opposite hose

- On the head part (1) it has two pins pointing downwards. Place this on the wire frame of the body. **Make sure that the tube is not pinched**

- Fix the head section with a cable tie (2) each on the body

- Before mounting, check the light for damage. The power supply may only take place after complete assembly

- The safety instructions and the technical data must be observed!

- The LED light works with 220-240 V alternating current

- The power socket must be near the lamp

- The power plug must be easily accessible at all times

- Select a suitable installation location

- Maintain a minimum distance of 3 m from swimming pools, ponds, etc.

- Make sure that the cable cannot become a tripping hazard

- Do not fix reindeer directly with staples ("staplers")

- No objects are hanging on the reindeer or sleigh

Switching on/ off

- The lamp is switched on by plugging in the mains plug and switched off again by pulling the plug

- Always pull out the mains plug when not in use for a long period of time

7. Cleaning/ storage



WARNING! Before cleaning the

LED light, pull out the mains plug.

Risk of electric shock! To clean

the entire LED light, just use a soft, lint-free cleaning cloth.

ATTENTION! Do not use abrasives or solvents under any circumstances, this applies to the entire LED light!



WARNING! Do not open the LED

light. Do not immerse in water or other liquids. Risk of electric shock!

When not in use, store the LED light in the original packaging in a dry, dust-free place.

8. Technical data

Operating voltage: 220-240 V ~/ 50-60 Hz

Output voltage: max. 18.7 W

Light source: 396 x LED warm white

Protection class: II, IP44

Conformity 

The product complies with the provisions of the following guidelines. Conformity is guaranteed by compliance with the standards listed.

2014/35/ EU Low Voltage Directive (LVD)

2014/30/ EU Electromagnetic Compatibility (EMC)

2011/65/ EU Restriction of (the use of certain) hazardous

	substances in electrical and electronic equipment (RoHS)
LVD	EN 60598-2-7
	EN 60598-2-21
	EN 60598-2-4
	EN 60598-2-20
EMC	EN 55015
	EN 61547
	EN 61000-3-2
	EN 61000-3-3

9. Disposal/ recycling



This product must not be disposed of with your other household waste.

As a consumer, you are obliged to return all electrical and electronic equipment for the proper disposal of this hazardous waste.

Dealers, manufacturers and importers, on the other hand, are obliged to take back old electrical and electronic equipment that they carry in their range free of charge.

The collection and recycling of electrical and electronic equipment conserves natural resources. In addition, health and the environment are protected by recycling electrical and electronic equipment. For more information about collection points and the disposal and recycling of electrical and electronic equipment, please contact the Federal Office for the Environment (FOEN), your local waste disposal company, the specialist dealer where you bought this device or the manufacturer of the device.